


## **OPERATION INSTRUCTION**

Side Type Dial Test Indicator 2898-08

6

Range: 0.8mm Graduation: 0.01mm Accuracy: 13µm Hysteresis: 3µm




- 1-Carbide contact point 2-Styli 3-Dovetail groove 4-Needle 5-Dial face 6-Bezel 7-Clamp(diameter Ø8mm)
- Caution: ---Prevent dust or liquid from getting into dial test indicator through the groove, otherwise the internal gear will be seized up(fig.1) ---Avoid the impact of the styli
- 1. The product with antimagnetic body has ceramic bearing.
- 2. Dial test indicator should be fixed firmly to use. It can be fixed by dovetail groove directly (fig.2), also can be fixed by clamp(fig.3).






fig.3


fig.2





Angle α	10°	20°	30°	40°	50°	60°
Correction	0.985	0.940	0.866	0.766	0.643	0.500

- For example: Angle  $\alpha$  is 10°, the correction is 0.985, if the reading is 0.15mm, then: True value = 0.15mm × 0.985 = 0.148mm
- 4. Each type of dial test indicator has specific length of styli (L, fig.6). If the length is not correct, measurement error will result. Please refer to the following table to choose correct styli.



(mm)

				()
Code	For dial test indicator	Material of contact point	L	D
6284-41		carbide	15.3	SØ1
6284-42		carbide	15.3	SØ2
6284-43	2898-08	carbide	15.3	SØ3
6284-44		carbide	15.3	SØ0.4
6284-45		ruby	15.3	SØ2



V0

fig.1